CABINET PARTS

REFRIGERATOR

For Models: GX5SHTXTQ00, GX5SHTXTB00, GX5SHTXTS00, GX5SHTXTT00
(White) (Black) (Stainless Steel) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GX5SHTXTQ00, GX5SHTXTB00, GX5SHTXTS00, GX5SHTXTT00
(White) (Black) (Stainless Steel) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	16025690	Tech Sheet
	12828178	Owners Manual
	12863069	Tag, Energy
2	8170414	Elbow, Fill Tube
3	8208254	Plate, Pivot
4	8170924	Gasket
5	67005127	Roller
6	4344155	Clip, Grille
8	67006287	Screw
9	67006521	Screw
10	12456801	Bracket, Roller
11	67006380	Screw
12	67006611	Bolt, Adjusting (Front)
13		Cover, Left Hinge
	8208247	White
	8208248	Black
	12684201C	Biscuit
14	67006303	Screw
15		Hinge, Center (RT)
	67006379	White
	67006443	Black
16	8208167	Block, Filter
17		Cover, Corner
	8170860	White
	8170858	Black
	8170859	Biscuit
18	12566603ED	Hinge, Top Left
19	67007174	Bracket, Foot (2)
20	67006564	Screw
21	8208257	Shim, Hinge
22		Grille Assembly (Includes Clips)
	67006377	White
	67006375	Black
	67006376	Biscuit
23	8208152	Track, Water Line
24		Hinge, Center (LH)
	8208392	White
	67006442	Black
25	67006425	Screw
26	8208155	Cover, Water Line
27	8208294	Cover, Water Valve
28	8208255	Screw
30	8170910	Cover, Unit
31	8208154	Fill Tube Assy.
32	67007121	Cord, Power
33	8171247	Insulation, Sound
34	8171272	Foot Brake
35	67006612	Bolt, Adjusting (Rear)
36	8171100	Clip
37	8170861	Tube, Drain
38	8170862	Clip, Drain Tube
39	8171038	Clamp, Tube
40		Cabinet (Not a Servicable Part)
41	8170974	Hinge, Top Right
42		Cover, Right Hinge
	8208261	White
	8208262	Black
	12684202C	Biscuit
43	4344287	Plug, Button
44	M1205302	Pin
45	M0286708	Nut, Speed
46	8170886	Roller Assembly

FREEZER LINER PARTS

For Models: GX5SHTXTQ00, GX5SHTXTB00, GX5SHTXTS00, GX5SHTXTT00
(White) (Black) (Stainless Steel) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: GX5SHTXTQ00, GX5SHTXTB00, GX5SHTXTS00, GX5SHTXTT00
(White) (Black) (Stainless Steel) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Seviceable Part)
2	8170897	Gasket, Foam
3	8171236	Gear (Left) (Includes Item 7)
4	8208205	Cover, Light
5	8171278	Shaft
6	8170839	Socket, Light
7	8171237	Gear (Right) (Includes Item 3)
8	67006473	Screw
9	A0282812	Bulb, Light
10	8170838	Housing, Light
11	67005873	Cover, Evaporator
12	67006425	Screw
13		Bracket, Door
	8171232	Left
	8171233	Right
14	8208206	Housing, Lighting
15	8208285	Clip, Evap Motor
16	8208349	Switch, Light
17	67006737	Screw
18		Bracket, Basket
	8171234	Left
	8171235	Right
19	67006607	Slide, Drawer (2)
20	8171083	Gasket, Bottom
21		Bracket, Slide
	8208215	Left
	8208216	Right
22	13024802	Cover, Fan Shroud
23	8171153	Shroud, Evap Fan
24	8170544	Blade, Fan (Evaporator)
25	8171086	Grommet (2)
26	8170894	Motor, Evaporator
27	4344385	Funnel, Drain
28	4344311	Seal
29	4344310	Gasket
30	8208196	Thermistor
31	8208202	Cover, Thermistor
32	67006406	Screw
33	67006530	Screw

Following Parts Not Illustrated

	67006095	Harness, Lights (Freezer)

REFRIGERATOR LINER PARTS

For Models: GX5SHTXTQ00, GX5SHTXTB00, GX5SHTXTS00, GX5SHTXTT00
(White) (Black) (Stainless Steel) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Models: GX5SHTXTQ00, GX5SHTXTB00, GX5SHTXTS00, GX5SHTXTT00
(White) (Black) (Stainless Steel) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	8208277	Bracket, Control and Lights
3	W10117528	Overlay
4	67004005	Housing Electronic Control
5	67006740	Electronic Control
6	4344571	Switch, Light
7	8208188	Cover, Light
8	8208189	Housing, Light
9	A0282812	Bulb, Light
10	8170839	Socket, Light
11	8208191	Insert, Damper Cover
12	67006602	Screw
13	8208193	Cover, Damper
14	8208194	Insulation
15	8208195	Control, Damper
16	8208196	Thermister
17	67003940	Switch (Energy Saver)
18	8171030	Plate
19	8171250	Tank, Water
20	67004694	Dispenser
21	67006287	Screw
23	67006524	Housing, Filter Head
24	8171033	Cover, Filter
25	67006470	Filter, Water
26	8171042	Head, Filter
28	67006400	Screw
29	8208276	Cover
30	8171036	Switch, Limit
31	8208165	Union

Following Parts Not Illustrated

	67004032	Harness, Control (Refrigerator) (Includes # 16)

REFRIGERATOR DOOR PARTS

For Models: GX5SHTXTQ00, GX5SHTXTB00, GX5SHTXTS00, GX5SHTXTT00
(White) (Black) (Stainless Steel) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: GX5SHTXTQ00, GX5SHTXTB00, GX5SHTXTS00, GX5SHTXTT00
(White) (Black) (Stainless Steel) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Door, Left
	13024006W	White
	13024006B	Black
	13024006S	Stainless Steel
	13024006Q	Biscuit
2	67003212	Mat
3	8171204	Compartment, Door (Includes Item 4)
4	8170793	Tray, Dairy
5	8171166	Bin, Shelf (3) (Medium)
6	8208251	Screw
7	8170956	Screw
8		Gasket, Door
	8208244	White
	8208245	Black
9		Door Handle
	2319729W	White
	2319729B	Black
	2319729S	Stainless
	2319729T	Biscuit
10	8171220	Stud, Handle
12	67003768	Bin, Shelf (2) (Large)
14		Mullion, Door
	67003434	White
	67004131	Black
	67005462	Biscuit
16		Closure, Door
	8171245	White
	8171246	Black
17		Stop, Door
	12968202W	White
	8208391	Black
	12968202Q	Biscuit
18		Plug, Button
	8208212	White
	8208213	Black
19		Bushing, Door (Upper Left)
	8208314	White
	8208256	Black
20		Bushing, Door (Upper Right)
	67002732	White
	8208264	Black
21	67006287	Screw
23		Door, Right
	13024005W	White
	13024005B	Black
	67006650	Stainless Steel
	13024005Q	Biscuit
25	8170797	Nameplate

UNIT PARTS

For Models: GX5SHTXTQ00, GX5SHTXTB00, GX5SHTXTS00, GX5SHTXTT00
(White) (Black) (Stainless Steel) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: GX5SHTXTQ00, GX5SHTXTB00, GX5SHTXTS00, GX5SHTXTT00
(White) (Black) (Stainless Steel) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	67006433	Screw
2	8208223	Blade, Fan
3	67005889	Base
4	67006425	Screw
5	8208234	Screw
7	12870501	Harness, Evap Heater
8	67007175	Pan, Drain
9	8171209	Grommet
10	8171085	Evaporator Heater
11	8208368	Capacitor
12	8171210	Overload (Includes Relay)
13	61003832	Gasket
14	8208287	Bi−Metal
15	8208321	Grommet (8)
17	67007052	Clip, Capacitor
18	67006131	Condenser
20	8171081	Tray, Drip
22	8171084	Evaporator

Illus. No.	Part No.	DESCRIPTION
23		Dam
	8171155	Right Side
	8171154	Left Side
24	8208221	Motor, Fan
25	4343918	Clip, Heater
26		Harness, Wiring
	67004080	Evap. Heater
	67004955	Unit
27	2317845	Drier (Service)
28	8208289	Compressor (Includes Items 11, 12, 17, 27 & 35)
31	8170906	Shroud
32	8208222	Bracket, Fan Motor
34	10547003	Clip, Drier
35	4343845	Grommet (4)
36	4344219	Clip, Evaporator
38	67006432	Screw
39	67006573	Screw
40	8171284	Tube, Discharge
41	67005149	Roller (2)
42	67006434	Axle

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated and Optional Parts Not Included

	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978028	Valve, Access (1/2")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")

REFRIGERANT CHARGE

5.0 Ozs.
(R−134A)

SHELF PARTS

For Models: GX5SHTXTQ00, GX5SHTXTB00, GX5SHTXTS00, GX5SHTXTT00
(White) (Black) (Stainless Steel) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SHELF PARTS

For Models: GX5SHTXTQ00, GX5SHTXTB00, GX5SHTXTS00, GX5SHTXTT00
(White) (Black) (Stainless Steel) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	8208331	Glass, Pantry
2	12654709	Shelf, Fixed
3	67006626	Screw
4	67006010	Support, Pantry(2)
5	8171056	Brace, Pantry (2)
6	8171046	Track, Pantry
7		Bracket, Glide
	67001053	Right
	67001054	Left
8	8171226	Divider, Upper Basket
9	8171054	Gasket, Pantry
10	67005625	Housing, Control
11	12654609	Shelf, Glass (3)
12	8208283	Slide, Temperature
13	67004585	Rack, Can
14	67007026	Glide, Drawer(2)
15	67006400	Screw
16		Track, Pantry
	67005863	Left
	67005858	Right
17	67004515	Pan, Crisper (2)
18	8208327	Support, Crisper Cover
19	67005721	Trim, Crisper
20	8208325	Frame, Crisper
21	8208324	Glass, Crisper Cover
22	8208336	Ladder, Center
23	8208337	Ladder, Side
24	67006400	Screw
25	67006360	Screw
26	67006415	Screw
27	8171049	Slide, Humidity Control
28	8208334	Rod, Temperature Control
29	8208335	Drawer, Pantry
30	8208170	Knob, Temperature Control
31	67005899	Door, Pantry Drawer
32	67006025	Basket, Freezer (Lower)
33	67006644	Divider, Lower Basket
34	8208338	Basket, Freezer (Upper)
35	8208220	Handle, Freezer Basket
36	67006287	Screw
37	8208326	Support, Center Crisper Frame
38	8208330	Stud, Crisper Frame
39	8208384	Divider, Pantry Drawer
40	67006104	Tray, Lower Basket

FREEZER DOOR PARTS

For Models: GX5SHTXTQ00, GX5SHTXTB00, GX5SHTXTS00, GX5SHTXTT00
(White) (Black) (Stainless Steel) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes Insulation)
	8171181	White
	8171179	Black
	8171178	Stainless Steel
	8171180	Biscuit
2		Handle
	2319729W	White
	2319729B	Black
	2319729S	Stainless Steel
3	67006408	Screw
4		Gasket, Door
	8171185	White
	8171186	Black
5	8170956	Screw
7		Plug, Button (2)
	8208212	White
	8208213	Black
9	8171220	Stud, Handle

ICEMAKER PARTS

For Models: GX5SHTXTQ00, GX5SHTXTB00, GX5SHTXTS00, GX5SHTXTT00
(White) (Black) (Stainless Steel) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1		Mold & Heater Assembly (Not Available −− Order 8170937)
2	8171289	Arm, Shutoff
3	8170928	Bearing & Inlet
4	8170927	Ejector
5	8170929	Ice Stripper
6	8170932	Support & Motor Assembly
7	8170930	Retainer, Thermostat
8		Thermostat (Not Available −− Order 8170937)
9	8170933	Screw (2)
10	8170926	Pan, Ice
11	8208157	Bracket, Tube Support
12	67006531	Valve, Water Inlet
13	4344402	Insert, Tube
14	8208151	Tubing, Plastic
15	67006614	Harness, Ice Maker
16	8170931	Bracket
17	67006662	Screw
18	8208238	Cover
19		Module Assembly (Not Available −− Order 8170937)
20	67006287	Screw
100	8170937	Complete Icemaker

Following Parts Not Illustrated

8170943	Screw, Bracket
8170944	Retainer, Tube
4343694	Screw
4344548	Coupling

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: GX5SHTXTQ00, GX5SHTXTB00, GX5SHTXTS00, GX5SHTXTT00
(White) (Black) (Stainless Steel) (Biscuit)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

Customer Touch−Up Material

	*350942	Primer, White (13 Oz. Spray Can)
	*350939	Enamel, Black (13 Oz. Spray Can)
	*350930	Enamel, White (13 Oz. Spray Can)
	72017	Brush Touch−Up Kit (White)
	72032	Brush Touch−up kit (Black)

*__Important:__ The spray paint is not to be used where the paint may make contact with the door gaskets.

Refinishing Material

	799340	Enamel, Black (1 Qt. Uncut)
	799344	Enamel, White (1 Qt. Uncut)

Miscellaneous

	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Kit, Insulation (2 Pcs. x 3" x 24" X 48")
	876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")
	978941	Insulation, Fiberglass (63−1/2" x 35−1/2" X 2−5/8)
	876029	Kit, Foam Slab (30" x 32−1/2" x 1−1/2")
	505587	Sealer, Mastic (1 Qt.)
	503695	Cork, Sealer (1/4 Pound)
	511873	Touch−Up, White Porcelain (2 Oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1−1/4 Oz.)
	606755	Bag, Insulation (36−5/8" x 46")
	799833	Kit, Evaporator Repair (Aluminum Epoxy)
	833938	Kit, Terminal Connector
	4343700	Ice Container Assembly

TORX SCREW WRENCH

	1117510	Torx Key